



AFE
BABALOLA
UNIVERSITY
ADO-EKITI (ABUAD)

KM. 8.5, AFE BABALOLA WAY,
ADO-EKITI, EKITI STATE, NIGERIA.
P.M.B 5454 ADO-EKITI.

System Response II

- Sinusoidal response
- Polar plot

By

Dr. Femi Onibonoje


Polar Plots

The standard first and second order system transfer functions are as follows.


First order form
$$\frac{\theta_o}{\theta_i}(s) = \frac{k}{Ts + 1}$$

Second Order form
$$\frac{\theta_o}{\theta_i}(s) = \frac{k}{T^2s^2 + 2T\delta s + 1}$$

When we have a sinusoidal input the steady state condition will produce an output that is also sinusoidal but with a different amplitude and a phase angle between them. Both signals may be represented by phasors as shown below. If the input has unit amplitude and held at zero degrees, the output phasor will form a phase angle ϕ to it and the length of the phasor will be the ratio of the amplitudes. Plotting vectors for all frequencies from $\omega = 0$ to $\omega = \infty$ produces a polar plot from which the amplitude ratio and phase angle can be seen for any frequency. This is one form of a frequency response diagram.



Phasors



Polar Plot

In order to produce this plot we change the transfer function into a function of $j\omega$ by replacing s with $j\omega$. The standard transfer functions become:

$$\frac{\theta_o}{\theta_i}(j\omega) = \frac{k}{j\omega T + 1}$$

$$\frac{\theta_o}{\theta_i}(j\omega) = \frac{k}{T^2(j\omega)^2 + 2T\delta j\omega + 1}$$

This is the Fourier transform. When this is done, the transfer function may be made into a complex number in the form $G = A + jB$. We may then plot the vector on the complex plane.

NOTE that in the steady state when $\omega = 0$ $G(j\omega) = k$ and this is the D.C. gain. T is a time constant and δ is the damping ratio.

The polar plot can be made for a closed loop or open loop system. The open loop is usually the easiest and there is an important reason for doing this which you will see later on when we look at stability.

Polar Plots of Some Basic Blocks

1. Integrator




Figure 2

$$\theta_o(t) = \int \theta_i dt \quad \theta_o(s) = s^{-1}\theta_i \quad \theta_o/\theta_i = 1/s \quad \text{Substitute } s = j\omega$$
$$\frac{\theta_o}{\theta_i}(j\omega) = \frac{1}{j\omega}$$

Multiply by the conjugate.
$$\frac{\theta_o}{\theta_i}(j\omega) = \frac{1}{j\omega} \times \frac{-j\omega}{-j\omega} = \frac{-j}{\omega}$$

The polar plot would be a line running from $-\infty$ to 0 on the $-j$ axis as shown. The radius is $1/\omega$ and the angle is -90° for all ω .

Polar Plots of Some Basic Blocks

2. Differentiator





Figure 3

$$\theta_o(t) = d\theta_i/dt \quad \theta_o(s) = s\theta_i \quad \theta_o/\theta_i = s$$

$$\text{Substitute } s = j\omega \quad \frac{\theta_o}{\theta_i}(j\omega) = j\omega$$

The polar plot would be a line running from 0 to ∞ on the $+j$ axis as shown. The radius is ω and the angle is $+90^\circ$ for all ω .

3. Exponential Delay

$$\theta_o(t) = e^{-t} \theta_i dt \quad \frac{\theta_o}{\theta_i}(s) = \frac{1}{1+s}$$




Figure 4

In the $j\omega$ form the transfer function becomes

$$\frac{\theta_o}{\theta_i}(j\omega) = \frac{1}{1+j\omega}$$

This is converted into a complex number by multiplying the top and bottom by the conjugate number.

$$\frac{\theta_o}{\theta_i}(j\omega) = \frac{(1-j\omega)}{(1+j\omega)(1-j\omega)} = \frac{(1-j\omega)}{(1+\omega^2)} = \frac{1}{1+\omega^2} - j\frac{\omega}{1+\omega^2}$$

$$\frac{\theta_o}{\theta_i}(j\omega) = A - jB \quad A = \frac{1}{(1+\omega^2)} \quad B = \frac{\omega}{(1+\omega^2)}$$

The polar plot is shown and formed by plotting the coordinates A and B for all values of ω .

The radius is $\frac{1}{\sqrt{1+\omega^2}}$ and the angle is $-\tan^{-1}(\omega)$

Frequency Response

First Order

In the $j\omega$ form the transfer function becomes

$$\frac{\theta_o}{\theta_i}(j\omega) = \frac{1}{1 + j\omega T}$$


This is converted into a complex number by multiplying the top and bottom by the conjugate number.

$$\frac{\theta_o}{\theta_i}(j\omega) = \frac{(1 - j\omega T)}{(1 + j\omega T)(1 - j\omega T)} = \frac{(1 - j\omega T)}{(1 - \omega^2 T^2)} = \frac{1}{1 - \omega^2 T^2} - j \frac{\omega T}{1 - \omega^2 T^2}$$


$$\frac{\theta_o}{\theta_i}(j\omega) = A - jB \quad A = \frac{1}{(1 + \omega^2 T^2)} \quad B = \frac{\omega T}{(1 + \omega^2 T^2)}$$

To obtain a polar plot we plot A horizontally and B vertically. If this is done for all frequencies over the range 0 to infinity, the resulting locus is called a frequency response diagram. This takes the form of a semi circle and reveals that at $\omega = 0$ the output and input have the same amplitude and the phase angle is zero. As the frequency increases, the amplitude of the output reduces to zero and the phase angle tends to 90° .

First Order




Imaginary j



From the geometry we find $\tan(-\phi) = B/A = \omega T$ so $-\phi = \tan^{-1} \omega T$

The ratio of the output amplitude to the input amplitude is $\frac{a_2}{a_1} = \frac{1}{\sqrt{1 + \omega^2 T^2}}$

This is the length of the vector. For any given frequency, the steady state plot θ_o and θ_i against time is typically as shown.



Second Order

The basic transfer function is

$$G(s) = \frac{1}{T^2 s^2 + 2T\delta s + 1}$$

$$G(j\omega) = \frac{1}{T^2(j\omega)^2 + 2T\delta j\omega + 1}$$

$$G(j\omega) = \frac{1}{(1 - T^2\omega^2) + 2T\delta j\omega}$$

$$G(j\omega) = \frac{1}{A + jB}$$

where $A = (1 - T^2\omega^2)$ and $B = 2T\delta\omega$

Multiply the top and bottom line by the conjugate number $A - jB$

$$G(j\omega) = \frac{A - jB}{(A + jB)(A - jB)}$$

$$G(j\omega) = \frac{A - jB}{\{A^2 + B^2\}} = C - jD$$

$$C = \frac{A}{A^2 + B^2} = \frac{(1 - \omega^2 T^2)}{\{(1 - \omega^2 T^2) + (2\delta\omega T)^2\}}$$

$$D = \frac{B}{A^2 + B^2} = \frac{2\delta T\omega}{\{(1 - T^2\omega^2)^2 + (2\delta\omega T)^2\}}$$

The polar plot is formed by plotting C horizontally and D vertically. If we plot for all frequencies from $\omega = 0$ to $\omega = \text{infinity}$ we get the following diagram.




Figure 8

The phase angle is found from $\phi = \tan^{-1} D/C$. The length of the vector is found from $G(s) = \sqrt{C^2 + D^2}$. This is the ratio of the amplitude of the output to the input. The overall result shows that at $\omega = 0$ the amplitudes are the same and in phase but as ω increases the amplitude of the output grows (depending on the value of δ) and then shrinks to zero as the phase angle increases to 180° .


Example 1

A simple first order system has the transfer function $\theta_o/\theta_i(s) = 1/(Ts + 1)$

The input is a sinusoidal signal. The system time constant is 0.2 seconds. Produce a polar plot of the locus of $\theta_o/\theta_i(j\omega)$ for frequencies from 0 to 100 rad/s.

SOLUTION

ω (Rad/s)	0	1	5	10	20	50	70	100
Mod(θ_o/θ_i)	1	0.98	0.707	0.447	0.243	0.1	0.07	0.05
ϕ (degrees)	0	-11.3	-45	-63.4	-75.96	-84.29	-85.91	-87.1



Example 2

A hydraulic cylinder is controlled by the transfer function $\theta_o/\theta_i = 1/(T^2s^2 + 2\delta Ts + 1)$

The time constant T is 0.02 Seconds and the damping ratio $\delta = 0.5$. The input is varied harmonically as $x_i = 20\sin(\omega t)$ at 15 rad/s, calculate the phase shift and amplitude of the output.

SOLUTION

$$\omega = 15 \quad \delta = 0.5 \quad T = 0.02$$

$$A = (1 - T^2\omega^2) = 1 - 0.02^2 \times 15^2 = 0.91$$

$$B = 2T\delta\omega = j 2 \times 0.02 \times 0.5 \times 15 = 0.3$$

$$C = \frac{A}{A^2 + B^2} = \frac{0.91}{0.91^2 + 0.3^2} = 0.991$$

$$D = \frac{B}{A^2 + B^2} = \frac{0.3}{0.91^2 + 0.3^2} = 0.327$$

$$\phi = \tan^{-1} D/C = \tan^{-1} 0.327/0.991 = -18.25^\circ$$

$$\text{Mod } \theta_o/\theta_i = \sqrt{C^2 + D^2} = \sqrt{0.991^2 + 0.327^2} = 1.043$$

It follows that the output amplitude is $1.043 \times 20 = 20.87$ and the phase angle is -18.25°

$$\theta_o(t) = 20.87 \sin(\omega t - 18.25^\circ)$$

HOMework

1. An electrical circuit has a resistor and capacitor has shown. Show that the transfer function is;

$$(V_o/V_i)(s) = 1/(Ts+1) \text{ where } T = RC$$




Figure 9

Given that $R = 47 \Omega$ and $C = 20 \mu\text{F}$ determine the output voltage when the input is sinusoidal such that $v_i = 5 \sin(2000 t)$.

Answer $2.35 \sin(2000t - 62^\circ)$

2. A standard second order system has the transfer function $x_o/x_i = 1/(T^2s^2 + 2\delta Ts + 1)$

The time constant T is 0.4 Seconds and the damping ratio $\delta = 0.2$. The input is varied harmonically as $\theta_i = 6 \sin(\omega t)$ at 2.5 rad/s. Calculate the phase shift and amplitude of the output.

(Answer 90° and 15)